

Start by configuring the Ethernet and the WLAN interfaces on the MR3020 in two different networks:

[/etc/config/network](#)

```
config interface 'loopback'
    option ifname 'lo'
    option proto 'static'
    option ipaddr '127.0.0.1'
    option netmask '255.0.0.0'

config interface 'wan'
    option ifname 'eth0'
    option proto 'static'
    option ipaddr '192.168.1.66'
    option netmask '255.255.255.0'
    option gateway '192.168.1.1'
    option dns '8.8.8.8'

config interface 'wifi'
    option proto 'static'
    option ipaddr '192.168.66.1'
    option netmask '255.255.255.0'
    option ip6addr '2a01:240:fe00:80ab::1/64'
```

[/etc/config/dhcp](#)

```
config dnsmasq
    option domainneeded 1
    option boguspriv 1
    option filterwin2k 0 # enable for dial on demand
    option localise_queries 1
    option rebind_protection 1 # disable if upstream must serve
RFC1918 addresses
    option rebind_localhost 1 # enable for RBL checking and similar
services
    #list rebind_domain example.lan # whitelist RFC1918 responses for
domains
    option local '/lan/'
    option domain 'lan'
    option expandhosts 1
    option nonegcache 0
    option authoritative 1
    option readethers 1
    option leasefile '/tmp/dhcp.leases'
    option resolvfile '/tmp/resolv.conf.auto'
    #list server '/mycompany.local/1.2.3.4'
    #option nonwildcard 1
    #list interface br-lan
    #list notinterface lo
    #list bogusnxdomain '64.94.110.11'
```

```
config dhcp wifi
  option interface    wifi
  option start        100
  option limit        150
  option leasetime    12h

config dhcp wan
  option interface    wan
  option ignore       1
```

[/etc/config/wireless](#)

```
config wifi-device    radio0
  option type          mac80211
  option channel       11
  option macaddr       f8:d1:11:bd:62:ce
  option hwmode        11ng
  option htmode        HT20
  list ht_capab        SHORT-GI-20
  list ht_capab        SHORT-GI-40
  list ht_capab        RX-STBC1
  list ht_capab        DSSS_CCK-40

config wifi-iface
  option device        radio0
  option network       wifi
  option mode          ap
  option ssid          'PocketBox'
  option encryption    'psk2'
  option key           '1CAFE2DECA'
```

[/etc/config/firewall](#)

```
config zone
  option name          wifi
  option input         ACCEPT
  option output        ACCEPT
  option forward       REJECT

config zone
  option name          lan
  option network       'lan'
  option input         ACCEPT
  option output        ACCEPT
  option forward       REJECT

config zone
  option name          wan
```

```
option network      'wan'
option input        REJECT
option output       ACCEPT
option forward      REJECT
option masq         1
option mtu_fix      1

config forwarding
option src          lan
option dest         wan

config forwarding
option src          wifi
option dest         wan
```

```
opkg update && opkg install aiccu radvd
```

```
ip -6 addr add 2a01:240:fe00:80ab::1/64 dev wlan0
```

[/etc/sysctl.conf](#)

```
net.ipv6.conf.all.forwarding=1
```

[/etc/config/radvd](#)

```
config interface
option interface    'wifi'
option AdvSendAdvert 1
option AdvManagedFlag 0
option AdvOtherConfigFlag 0
list client        ''
option ignore       0

config prefix
option interface    'wifi'
# If not specified, a non-link-local prefix of the interface is
used
list prefix         '2a01:240:fe00:80ab::/64'
option AdvOnLink    1
option AdvAutonomous 1
option AdvRouterAddr 0
option ignore       0

config route
option interface    'wifi'
list prefix        ''
option ignore       1
```

```
config rdns
  option interface      'wifi'
  # If not specified, the link-local address of the interface is used
  list addr            ''
  option ignore        1

config dnssl
  option interface      'wifi'
  list suffix          ''
  option ignore        1
```

Create and edit

[/etc/aiccu.conf](#)

```
# AICCU Configuration

# Login information (defaults: none)
username SLH4-SIXXS
password 8FEBkBr7

# Protocol and server to use for setting up the tunnel (defaults: none)
#protocol <tic|tsp|l2tp>
#server <server to use>

# Interface names to use (default: aiccu)
# ipv6_interface is the name of the interface that will be used as a
# tunnel interface.
# On *BSD the ipv6_interface should be set to gifX (eg gif0) for
# proto-41 tunnels
# or tunX (eg tun0) for AYIYA tunnels.
ipv6_interface tun0

# The tunnel_id to use (default: none)
# (only required when there are multiple tunnels in the list)
tunnel_id T23724

# Be verbose? (default: false)
verbose true

# Daemonize? (default: true)
# Set to false if you want to see any output
# When true output goes to syslog
#
# WARNING: never run AICCU from DaemonTools or a similar automated
# 'restart' tool/script. When AICCU does not start, it has a reason
# not to start which it gives on either the stdout or in the (sys)log
# file. The TIC server *will* automatically disable accounts which
# are detected to run in this mode.
#
```

```
daemonize true

# Automatic Login and Tunnel activation?
automatic true

# Require TLS?
# When set to true, if TLS is not supported on the server
# the TIC transaction will fail.
# When set to false, it will try a starttls, when that is
# not supported it will continue.
# In any case if AICCU is build with TLS support it will
# try to do a 'starttls' to the TIC server to see if that
# is supported.
requiretls false

# PID File
#pidfile /var/run/aiccu.pid

# Add a default route (default: true)
#defaultroute true

# Script to run after setting up the interfaces (default: none)
#setupscript /usr/local/etc/aiccu-subnets.sh

# Make heartbeats (default true)
# In general you don't want to turn this off
# Of course only applies to AYIYA and heartbeat tunnels not to static
ones
#makebeats true

# Don't configure anything (default: false)
#noconfigure true

# Behind NAT (default: false)
# Notify the user that a NAT-kind network is detected
behindnat true

# Local IPv4 Override (default: none)
# Overrides the IPv4 parameter received from TIC
# This allows one to configure a NAT into "DMZ" mode and then
# forwarding the proto-41 packets to an internal host.
#
# This is only needed for static proto-41 tunnels!
# AYIYA and heartbeat tunnels don't require this.
#local_ipv4_override
```

```
aiccu start
/etc/init.d/radvd start
/etc/init.d/radvd enable
```

From:

<http://wiki.lahoud.fr/> - **wikiroute**

Permanent link:

http://wiki.lahoud.fr/doku.php?id=ipv6_tunnel_at_home&rev=1428159699

Last update: **2015/04/04 17:01**

