

# Introduction

The TP-LINK MR-3020 has gained a growing success recently. This portable wireless router supports IEEE 802.11 b/g/n standards and has one 100 Mbps LAN/WAN port, a USB 2.0 Port for 3G/4G modem, and a mini USB Port for power supply. The portability of the MR-3020 made it an excellent solution for the [PirateBox](#) project and, as [recently announced](#) by RIPE NCC, the future measurement probe of the [ATLAS](#) project.

## Basic Configuration

Start by getting the Attitude Adjustment build of the [OpenWRT firmware](#) and proceed as in the following. Connect to the TL-MR3020 router via Ethernet cable at IP address 192.168.0.254, log in to the router's web GUI (default login/password: admin / admin) and overwrite the factory firmware by installing the downloaded firmware image like a regular firmware update. Wait for the progress bar to finish twice (the device will reset itself in the process), and proceed with basic configuration as with any fresh OpenWRT install. With OpenWRT the default IP address of the router is 192.168.1.1. Connect to the router via Ethernet cable using telnet or web GUI. The router should now be configured to connect to the Internet. The following example supposes that the MR-3020 router is connected to a gateway configured with 192.168.1.1.

```
# vi /etc/config/network
config interface 'lan'
    option ifname 'eth0'
    option type 'bridge'
    option proto 'static'
    option ipaddr '192.168.1.66'
    option netmask '255.255.255.0'
    option gateway '192.168.1.1'
    list dns '192.168.1.1'
    list dns '8.8.8.8'

#vi /etc/config/wireless
config wifi-device 'radio0'
    option type 'mac80211'
    option channel '11'
    option macaddr 'f8:d1:11:bd:62:ce'
    option hwmode '11ng'
    option htmode 'HT20'
    list ht_capab 'SHORT-GI-20'
    list ht_capab 'SHORT-GI-40'
    list ht_capab 'RX-STBC1'
    list ht_capab 'DSSS_CCK-40'
    option disabled '0'
    option txpower '27'
    option country 'FR'
```

```
config wifi-iface
    option device 'radio0'
    option network 'lan'
    option mode 'ap'
    option ssid 'addroute'
    option encryption 'psk2'
    option key 'hello'
```

Reboot the routeur by typing `reboot` or simply unplugging the USB cable. Connect via SSH at 192.168.1.66 and verify that the internet connection is active.

## Extroot configuration

Update the packages and install the necessary tools to migrate rootfs on external storage

```
opkg update && opkg install kmod-usb-core kmod-usb2 kmod-usb-storage kmod-
fs-ext4 block-mount kmod-usb-uhci kmod-usb-ohci
```

On a linux machine, plug a usb external drive or a memory stick. Start by wiping existing partition table from USB memory stick. In order to identify the name of the corresponding device, take a look at `/var/log/syslog`. Typedd `if=/dev/zero of=/dev/sda bs=64k count=1`

Partition USB memory stick with 64M swap, 256M root and rest as third partition

```
cat | fdisk /dev/sda <<__EOF__
n
p
1
1
+64M
t
82
n
p
2
+256M
n
p
3
w
q
__EOF__
```

Verify the created partitions:

```
root@OpenWrt:~# fdisk -l /dev/sda
```

```
Disk /dev/sda: 4206 MB, 4206886912 bytes
130 heads, 62 sectors/track, 1019 cylinders
Units = cylinders of 8060 * 512 = 4126720 bytes
Disk identifier: 0xcb85d70e
```

```
Device Boot Start End Blocks Id System
/dev/sda1 1 17 68479 82 Linux swap / Solaris
/dev/sda2 18 80 253890 83 Linux
/dev/sda3 81 1019 3784170 83 Linux
```

Create swap and filesystems, also set unique label in addition to automatically generated uuid

```
mkswap /dev/sda1 -L ow_swap_`dd if=/dev/urandom bs=1k count=1|tr -dc "a-f0-9"|cut -c1-6`
mkfs.ext3 /dev/sda2 -L ow_root_`dd if=/dev/urandom bs=1k count=1|tr -dc "a-f0-9"|cut -c1-6`
mkfs.ext3 /dev/sda3 -L ow_data_`dd if=/dev/urandom bs=1k count=1|tr -dc "a-f0-9"|cut -c1-6`
```

Check label and uuid with blkid command

```
root@OpenWrt:~# blkid
/dev/mtdblock2: TYPE="squashfs"
/dev/sda1: TYPE="swap" LABEL="ow_swap_53bdb3" UUID="3ebd4c59-fffd-47b5-b598-136ff740a20f"
/dev/sda2: LABEL="ow_root_f479b3"
UUID="0b4dfe19-3f7d-4579-983c-452ed9e4bc83" SEC_TYPE="ext2" TYPE="ext3"
/dev/sda3: LABEL="ow_data_8505fb"
UUID="a6ca6666-7639-4825-9eee-727718affd19" SEC_TYPE="ext2" TYPE="ext3"
```

Configure swap to be enabled on next boot

```
/etc/init.d/fstab stop
uci delete fstab.@swap[0]
uci commit fstab
uci add fstab swap
# Works with /dev/sda1 as device
#uci set fstab.@swap[-1].device=/dev/sda1
# Fails with label
#uci set fstab.@swap[-1].label=`blkid -s LABEL /dev/sda1 | cut -d\" -f2`
# Fails with uuid
uci set fstab.@swap[-1].uuid=`blkid -s UUID /dev/sda1 | cut -d\" -f2`
uci set fstab.@swap[-1].enabled=1
uci commit fstab
```

Configure extroot to be mounted on next boot

```
uci delete fstab.@mount[0]
uci commit fstab
uci add fstab mount
```

```
# Works with /dev/sda2 as device
#uci set fstab.@mount[-1].device=/dev/sda2
# Fails with label
#uci set fstab.@mount[-1].label=`blkid -s LABEL /dev/sda2 | cut -d\" -f2`
# Fails with uuid
uci set fstab.@mount[-1].uuid=`blkid -s UUID /dev/sda2 | cut -d\" -f2`
uci set fstab.@mount[-1].options=rw,sync,noatime
uci set fstab.@mount[-1].fstype=ext3
uci set fstab.@mount[-1].enabled_fsck=1
uci set fstab.@mount[-1].enabled=1
uci set fstab.@mount[-1].target=/
# or with target=/overlay if using overlay mode
uci commit fstab # Configure data partition to be mounted on next boot
mkdir -p /mnt/data
uci add fstab mount
# Works with /dev/sda3 as device
#uci set fstab.@mount[-1].device=/dev/sda3
# Fails with label
#uci set fstab.@mount[-1].label=`blkid -s LABEL /dev/sda3 | cut -d\" -f2`
# Fails with uuid
uci set fstab.@mount[-1].uuid=`blkid -s UUID /dev/sda3 | cut -d\" -f2`
uci set fstab.@mount[-1].options=rw,sync,noatime
uci set fstab.@mount[-1].fstype=ext3
uci set fstab.@mount[-1].enabled_fsck=1
uci set fstab.@mount[-1].enabled=1
uci set fstab.@mount[-1].target=/mnt/data
uci commit fstab
# Disable anon mount feature
uci set fstab.automount.anon_mount=0
uci commit fstab
```

Check the resulting `/etc/config/fstab`:

```
root@OpenWrt:~# cat /etc/config/fstab
config 'global' 'automount'
  option 'from_fstab' '1'
  option 'anon_mount' '0'
config 'global' 'autoswap'
  option 'from_fstab' '1'
  option 'anon_swap' '0'
config 'swap'
  option 'uuid' '3ebd4c59-fffd-47b5-b598-136ff740a20f'
  option 'enabled' '1'
config 'mount'
  option 'uuid' '0b4dfe19-3f7d-4579-983c-452ed9e4bc83'
  option 'options' 'rw,sync,noatime'
  option 'fstype' 'ext3'
  option 'enabled_fsck' '1'
  option 'enabled' '1'
  option 'target' '/'
config 'mount'
```

```
option 'uuid' 'a6ca6666-7639-4825-9eee-727718affd19'
option 'options' 'rw,sync,noatime'
option 'fstype' 'ext3'
option 'enabled_fsck' '1'
option 'enabled' '1'
option 'target' '/mnt/data'
```

Populate new rootfs with content of existing rootfs

```
mkdir -p /mnt/sda2 /tmp/cproot
mount --bind / /tmp/cproot
mount /dev/sda2 /mnt/sda2
tar -C /tmp/cproot -cvf - . | tar -C /mnt/sda2 -xf -
sync; umount /mnt/sda2 ; umount /tmp/cproot
```

Activate extroot on next boot

```
/etc/init.d/fstab enable
/etc/init.d/fstab start
/etc/init.d/fstab whole_root_enable
# or if using overlay mode
#/etc/init.d/fstab overlay_enable
```

Reboot router reboot # Login and check mounts after restart Looks like extroot is not working but data partition was properly mounted with uuid

```
root@OpenWrt:~# df -h
Filesystem Size Used Available Use% Mounted on
rootfs 1.5M 848.0K 688.0K 55% /
/dev/root 1.5M 1.5M 0 100% /rom
tmpfs 14.4M 64.0K 14.3M 0% /tmp
tmpfs 512.0K 0 512.0K 0% /dev
/dev/mtdblock3 1.5M 848.0K 688.0K 55% /overlay
overlayfs:/overlay 1.5M 848.0K 688.0K 55% /
/dev/sda2 240.1M 12.0M 215.7M 5% /tmp/whole_root-disabled
/dev/sda3 3.6G 71.3M 3.3G 2% /mnt/data
```

Check that uuid's are still in place with blkid

```
root@OpenWrt:~# blkid
/dev/mtdblock2: TYPE="squashfs"
/dev/sda1: TYPE="swap" LABEL="ow_swap_53bdb3" UUID="3ebd4c59-fffd-47b5-
b598-136ff740a20f"
/dev/sda2: LABEL="ow_root_f479b3"
UUID="0b4dfe19-3f7d-4579-983c-452ed9e4bc83" SEC_TYPE="ext2" TYPE="ext3"
/dev/sda3: LABEL="ow_data_8505fb"
UUID="a6ca6666-7639-4825-9eee-727718affd19" SEC_TYPE="ext2" TYPE="ext3"
```

Swap seems to be enabled

```
root@OpenWrt:~# free
total used free shared buffers
Mem: 29436 17936 11500 0 2244
-/+ buffers: 15692 13744
Swap: 68472 0 68472
```

Switch from uuid's to device names

```
uci delete fstab.@swap[-1].uuid
uci set fstab.@swap[-1].device=/dev/sda1
uci delete fstab.@mount[0].uuid
uci set fstab.@mount[0].device=/dev/sda2
uci delete fstab.@mount[1].uuid
uci set fstab.@mount[1].device=/dev/sda3
uci commit
```

Resulting /etc/config/fstab

```
root@OpenWrt:~# cat /etc/config/fstab
config 'global' 'automount'
  option 'from_fstab' '1'
  option 'anon_mount' '0'
config 'global' 'autoswap'
  option 'from_fstab' '1'
  option 'anon_swap' '0'
config 'swap'
  option 'enabled' '1'
  option 'device' '/dev/sda1'
config 'mount'
  option 'options' 'rw,sync,noatime'
  option 'fstype' 'ext3'
  option 'enabled_fsck' '1'
  option 'enabled' '1'
  option 'target' '/'
  option 'device' '/dev/sda2'
config 'mount'
  option 'options' 'rw,sync,noatime'
  option 'fstype' 'ext3'
  option 'enabled_fsck' '1'
  option 'enabled' '1'
  option 'target' '/mnt/data'
  option 'device' '/dev/sda3'
```

Re-enable extroot

```
/etc/init.d/fstab enable
/etc/init.d/fstab start
/etc/init.d/fstab whole_root_enable
```

Reboot and check if extroot is working

```
root@OpenWrt:~# df -h
Filesystem Size Used Available Use% Mounted on
rootfs 240.1M 12.0M 215.7M 5% /
/dev/root 1.5M 1.5M 0 100% /rom
tmpfs 14.4M 60.0K 14.3M 0% /tmp
tmpfs 512.0K 0 512.0K 0% /dev
/dev/sda2 240.1M 12.0M 215.7M 5% /
/dev/sda3 3.6G 71.3M 3.3G 2% /mnt/data
```

Yes, seems to work now !

From:

<http://wiki.lahoud.fr/> - **wikiroute**

Permanent link:

[http://wiki.lahoud.fr/doku.php?id=mr3020\\_with\\_openwrt&rev=1357775890](http://wiki.lahoud.fr/doku.php?id=mr3020_with_openwrt&rev=1357775890)

Last update: **2014/01/11 05:25**

